# LSV5-08-2 NCS

2-Way,2-Position,Normally closed, Spool-type Solenoid Valve

#### **DESCRIPTION**

# A solenoid operated, 2-way, 2-position, normally closed, spool-type cartridge valve.

#### **OPERATION**

When de-energized, the valve blocks flow in both directions. When energized, the cartridge's spool shifts to allow flow in both directions.

# **Operation of Manual Override Option**

To override, push button in, twist counterclockwise 180° and release. In this position, the valve will remain open in a detented condition. To return to normal operation, push button in, twist clockwise 180° and release. Override will be detented in this position.

#### **SYMBOL**




#### **SPECIFICATIONS**


Operating Pressure	315bar
Flow	See PRESSURE DROP VS.FLOW graph.
Internal Leakage	82 cc/min max. at 280bar
Temperature	-40°F to +212°F(-40°C to +100°C)
Coil Duty Rating	Continuous from 85% to 115% of nominal voltage
Filtration	See page N-1
Fluids	Mineral-based fluids with viscosities of 7.4 to 420 cSt.
Cavity	08-2,See page M-1

Housing Material

6061-T6 aluminum alloy rated to 207bar, Steel & Ductile iron rated to 350bar



# PRESSURE DROP VS.FLOW





### **TO ORDER**



1 Function

LSV5=Solenoid Valve

2 Size

08=08 Size

3 Flow Path

2=2-Way

4 Style

NC=Normally Closed

5 **Type** 

S=Spool

6 Manual Override Options

Omit=None

M=Manual Override

7 Coil Voltage

**1**=12 **VDC 2**=24 **VDC** 3=110 VAC

4=220

**5**=10

VAC **VDC** 

# **Coil Connector Type**

D= Double Lead

H= Hirschmann

C= Conduit

ER= Deutsch Connector(Water-proof Coil)

B= Double Spade

9 Port Size

Omit=None

4T=SAE 4

6T=SAE 6

2G=G 1/4

3G=G 3/8

XSee page K-1 for detail of

housing

X Other port sizes are available

# **INSTALLATION DIMENSIONS**

Coil Must Be Installed With Letter Up

Unit=Millimeters

