LSV2-08-3A

3-Way,2-Position, Spool-type Solenoid Valve

DESCRIPTION

A solenoid operated, 3-way, 2-position, spool-type cartridge valve.


OPERATION

When de-energized, the valve allows flow from 3 to 2 or from 2 to 3, while blocking flow at 1. When energized, the cartridge's spool shifts to allow flow from 1 to 2 or from 2 to 1, while blocking flow at 3.

Operation of Manual Override Option

To override, push button in, twist counterclockwise 180° and release. In this position, valve will remain detented in the shifted condition. To return to normal operation, push button in, twist clockwise 180° and release. Override will be detented in this position.

SYMBOL




SPECIFICATIONS


Operating Pressure	207bar
Flow	See PERFORMANCE CHARACTERISTIC grap.
Internal Leakage	(per land)82cc/min max. at 207bar
Temperature	-40°F to +212°F(-40°C to +100°C)
Coil Duty Rating	Continuous from 85% to 115% of nominal voltage
Filtration	See page N-1
Fluids	Mineral-based fluids with viscosities of 7.4 to 420 cSt.
Cavity	08-3,See page M-1

Housing Material

6061-T6 aluminum alloy rated to 207bar, Steel & Ductile iron rated to 350bar




PRESSURE DROP VS.FLOW





TO ORDER



1 Function

LSV2=Solenoid Valve

Size

08=08 Size

3 Flow Path

3A=3-Way

Manual Override Options

Omit=None

M=Manual Override

5 Coil Voltage

1 =12	VDC
2 -24	VDC

- VAC 3=110
- VAC 4=220 5=10 **VDC**
- **7**=48 **VDC**
- 8=24 VAC

6 Coil Connector Type

- D= Double Lead
- S= Single Lead
- H= Hirschmann
- ER= Deutsch Connector(Water-proof Coil)
- E= Single Stud
- B= Double Spade

7 Port Size

Omit=None

- 4T=SAE 4
- 6T=SAE 6
- 2G=G 1/4
- **3G**=G 3/8
- X See page K-2 for detail of housing
- **X** Other port sizes are available

INSTALLATION DIMENSIONS

Coil Must Be Installed With Letter Up

Unit=Millimeters

