LSV2-08-3C

3-Way,2-Position, Spool-type Solenoid Valve

DESCRIPTION

A solenoid operated, 3-way, 2-position, spool-type cartridge valve.

OPERATION

When de-energized, the valve allows flow from 3 to 1 or from 1 to 3 ,while blocking flow at 2. When energized, the cartridge's spool shifts to allow flow from 2 to 1 or from 1 to 2, while blocking flow at 3.

While port ① may be fully pressurized, it is not intended to be used as the inlet.

Operation of Manual Override Option

To override, push button in, twist counterclockwise 180° and release. In this position, valve will remain detented in the shifted condition. To return to normal operation, push button in, twist clockwise 180° and release. Override will be detented in this position.

SYMBOL




SPECIFICATIONS


Operating Pressure	207bar
Flow	See PERFORMANCE CHARACTERISTIC graph.
Internal Leakage	(per land)82cc/min max. at 207bar
Temperature	-40°F to +212°F(-40°C to +100°C)
Coil Duty Rating	Continuous from 85% to 115% of nominal voltage
Filtration	See page N-1
Fluids	Mineral-based fluids with viscosities of 7.4 to 420 cSt.
Cavity	08-3,See page M-1

Housing Material

6061-T6 aluminum alloy rated to 207bar, Steel & Ductile iron rated to 350bar




PRESSURE DROP VS.FLOW





TO ORDER



VDC

VAC

1 Function

LSV2=Solenoid Valve

Size

08=08 Size

3 Flow Path

3C=3-Way

Manual Override Options

Omit=None

M=Manual Override

- 5 Coil Voltage
 - **1**=12
 - **2**=24 **VDC** VAC
 - 3=110 4=220
 - VAC **VDC**
 - 5=10
 - **7**=48 **VDC**
 - 8=24
- 6 Coil Connector Type
 - D= Double Lead
 - S= Single Lead
 - H= Hirschmann
 - ER= Deutsch Connector(Water-proof Coil)
 - E= Single Stud
 - B= Double Spade

7 Port Size

Omit=None

- 4T=SAE 4
- 6T=SAE 6
- 2G=G 1/4
- **3G**=G 3/8
- X See page K-2 for detail of housing
- **X** Other port sizes are available

INSTALLATION DIMENSIONS

Coil Must Be Installed With Letter Up

Unit=Millimeters

